

# Flow chart of push button menu for aSENSE<sup>®</sup> m III

**Display modes**  
(LCD contents)

**Maintenance functions menu**  
(with LCD "texts")

**Functions executed**

